


Let's Assembly

Jayden Dining Chair

SKU 200220 / 200222



The parts

	Description	Qty	
A	Chair Back	1	
B	Seat Cushion W/ Frame Cover	1	
C	Seat Frame	1	
D	Front Leg	2	

What you need

- Use the packaging carton as a working surface to prevent product damage during assembly
- Phillips Screwdriver

Estimated time for assembly

25 minute

Do not use power tools









Weight Limitation




Need Help?

Toll-free at 1-888-909-5546
Help@allforwood.com

Description		Qty	
1	1/4 x 1 1/2 inch Hex Button Head Bolt	2	
2	1/4 x 2 3/8 inch Hex Button Head Bolt	4	
3	1/4 x 3 1/8 inch Hex Button Head Bolt	4	
4	Ø1/4 inch Lock Washer	10	
5	Ø1/4 inch Flat Washer	10	
6	Ø10 x 30mm Wooden Dowel (Extra 1pcs)	2	
7	Allen Key	1	
8	Plastic Nailhead Feet (extra)	2	

The product

Exploded View



IMPORTANT

1. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes
2. Do not over tighten screws and bolts to avoid stripping
3. . Please use hand tools to assemble this product. Do not use power tools.

Step 1

Secure on the Chair Back (A) and the Seat Frame (C) using the Flat Washer (5), Lock Washer (4) and Hex Button Head Bolt (1). Tighten to 75% using the Allen Key (7).




x2 PCS




x2 PCS



x2 PCS



x1 PC



Step 2

Let's secure those legs in place!
Secure using the Flat Washers (5), Lock Washers (4)
and Hex Button Head Bolts (3).
Tighten to 75% using the Allen Key (7).




x4 PCS



x4 PCS



x4 PCS



Step 3


Secure on the Front Legs (D) and the Seat Frame (C) using the Flat Washer (5), Lock Washer (4) and Hex Button Head Bolt (2). Tighten to 75% using the Allen Key (7).



x4 PCS


x4 PCS

x4 PCS




Step 4

First, cover the Seat Cushion w/
Frame Cover (B) on the face of the
seat frame and then secure the
Velcro sides.




Step 5

Carefully flip the stool over on a flat surface and make sure the legs are touching the ground evenly before tightening everything to 100%.



Ready to use



Prioritize safety

To ensure the longevity of your product we suggest tightening the screws a couple weeks after assembly. For added safety, please check and tighten all screws every two months.

For detailed care and maintenance instructions for the seat and wood, please visit our website at allforwood.com/product.

Proper use	DO NOT - Alter the structure of this product DO NOT - Utilize for commercial purposes DO NOT - Play on the chair DO NOT - Use the chair as a foot stool DO NOT - Leave spilled liquids on the seat DO NOT - Use the chair if it is damaged DO NOT - Perform temporary repairs DO NOT - Use outdoors
-------------------	--

The return

Stress-free returns when we take care of it.

Feel free to call us at

1-888-909-5546

or send us a message at

help@allforwood.com.

We'll provide you with a hassle-free replacement at no cost.

Replacement



Give us a call or email



Replacement



You

Return



Re-package item



Schedule pick up



Track package



Replacement



You

We really want to save you the trouble of re-packaging and returning your item, because let's be honest, no one has time for that.

Warranty

This product includes a specific warranty period starting from the purchase date.
To register your product, simply scan the QR code with your phone

Scan me!

For Warranty



Need Help?

Toll-free at 1-888-909-5546

Help@allforwood.com

www.allforwood.com