














Let's Assembly

# Swivel Counter Stool

SKU 202000/202010



# The parts

	Description	Qty	
A	Leg Frame Top	1	
B	Leg Frame Bottom	1	
C	Footrest	1	
D	Swivel Plate	1	
E	Cushion Seat	1	
1	1/4 x 40mm Hex Button Head Bolt	1	
2	1/4 x 30mm Hex Button Head Bolt	4	
3	1/4 x 20mm Hex Button Head Bolt	8	
4	1/4 x 10mm Lock Washer	12	
5	1/4 x 16mm Lock Washer	12	
6	Allen Key	1	
7	Leveler (Extra)	2	

## What you need

- Use the packaging carton as a working surface to prevent product damage during assembly
- Some of your favourite bubbly or your preferred relaxant

## Estimated time for assembly

**30 minute**

## Do not use power tools



## Weight Limitation




## Need Help?

Toll-free at 1-888-909-5546  
Help@allforwood.com

# The product

## Exploded View




### IMPORTANT

1. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes
2. Do not over tighten bolts to avoid stripping
3. . Please use hand tools to assemble this product. Do not use power tools.

# Step 1





Let's get this thing fired up!

Attach the two leg frames with the cut connect.




# Step 2

Attach swivel plate with leg frame.  
Important! Please rotate 45° on swivel plate.



# Step 3

Flip the legs over and attach the cushioned seat!



x1




x4



x4



x4



# Step 4

Wiggle on the footrest to the leg frame.





x4



x4




x4



Do NOT overtighten hardware.  
Tighten only to 75% for now.

# Step 5


Ensure all legs are touching the ground by using Leveler.



Foot levelers can be adjusted for a perfect level finish



# Ready to use



## Prioritize safety

To ensure the longevity of your Counter Stool

For detailed care and maintenance instructions for the, please visit our website at [allforwood.com/product](https://allforwood.com/product).

<b>Proper use</b>	<b>DO NOT</b> - Modify the structure of this product
	<b>DO NOT</b> - Use for commercial purposes
	<b>DO NOT</b> - Play on the stool
	<b>DO NOT</b> - Leave spilled liquids on the stool
	<b>DO NOT</b> - Use the stool if it is damaged
	<b>DO NOT</b> - Perform temporary repairs
	<b>DO NOT</b> - Use outdoors

# The return

Stress-free returns when we take care of it.

Feel free to call us at

**1-888-909-5546**

or send us a message at

**help@allforwood.com.**

We'll provide you with a hassle-free replacement at no cost.

## Replacement



Give us a call or email



Replacement



You

## Return



Re-package item



Schedule pick up



Track package



Replacement



You

We really want to save you the trouble of re-packaging and returning your item, because let's be honest, no one has time for that.

# Warranty

This product includes a specific warranty period starting from the purchase date.  
To register your product, simply scan the QR code with your phone

## Scan me!

For Warranty



### Need Help?

Toll-free at 1-888-909-5546

Help@allforwood.com

www.allforwood.com