
Let's Assembly

Dining Table

SKU 400200





The parts

Description	Qty	
A Table Top	2	
B Top Extension Leaves	2	
C Legs	4	
D Extension Support Bar	4	
E Metal Plate	2	
F Metal Connector	1	
G Metal Support Rail	2	0

What you need

- Use the packaging carton as a working surface to prevent product damage during assembly
- Phillips Screwdriver


Estimated time for assembly

30-45 minute

Do not use power tools



Weight Limitation




Need Help?

Toll-free at 1-888-909-5546 Help@allforwood.com

	Description	Qty	
1	1/4 x 2.36 inch Plastic Head Bolt	12 + 2 Extra	
2	5 /16 x 2.36 inch Hex Button Head Bolt	2 + 2 Extra	
3	1/4 x 1 inch Hex Button Head Bolt	30 + 2 Extra	
4	1/4 inch Lock Washer	2 + 2 Extra	
5	1/4 inch Flat Washer	14 + 2 Extra	
6	M8 x 1.18 inch Wood Dowel	4 + 2 Extra	
7	Allen Key	1	8
8	Leveler	2 Extra	
9	Wedge Spacer	2	

The product

Exploded View



IMPORTANT

- 1. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes
- 2. Do not over tighten bolts to avoid stripping
- 3. . Please use hand tools to assemble this product. Do not use power tools.


Start by stacking the Leg frames (C) as shownon a soft surface or towel to prevent scratches.



(5)

x6

Take the Metal Plate (E) attach to the Leg Frames (C) using the Bolt (3) and the Allen Key (7), make sure the center joints between the Leg Frame (C) is flat then tighten everything to 100%



Step 2

Laying out the Table Top (A) with Wegde Spacer (9) as shown on a soft surface or towel to prevent scratches.






x2


x2

Take the Metal Conector (3) attach it to the Table Tops (A) Using the Bolt (3) and the Allen Key (7), tighten to 100%




Attach the Metal Support Bar (G) to the Metal connector (F) Tighten to 100%





Step 4


Attach the assembled leg frames to the Table Top (A)



Using the Bolt (2), the Lock Washer (4), the Flat Washer (5) and the Allen Key (7). Tighten to 100% Then use the Bolt (3) and the Allen Key (7). Tighten to 100%








(5)

x1


x1

Step 6


Attach the remaining assembled leg frames to the Table Top (A)




Using the Bolt (2), the Lock Washer (4), the Flat Washer (5) and the Allen Key (7). Tighten to 100% Then use the Bolt (3) and the Allen Key (7). Tighten to 100%



Slide the Extension Support Bars (D) into the holes






Now your Table is ready to use without extension leaves




Step 12

For use with extension leaves, remove the inner Platicts Head Bolts (1) and Flat Washer (5) Untighten the remaining Platicts Head Bolts (1) then pull out the Extension Support Bars completely




Put the Wood Dowel (6) to the predrilled holes






Step 14

Place the Top Extension Leaves (B) on the Extension Support Bar (D) Make sure to line up their corresponding holes




Attach the Extension Support Rail (D) to the Top Extension Leaves (B). Using the Plastic Head Bolts (1) and Flat Washer (5) removed from step 12 Tighten to 100%






Step 16

Ensure all legs are touching the ground by using Leveler.



Ready to use



Prioritize safety

To ensure the longevity of your Dining Table

For detailed care and maintenance instructions for the, please visit our website at allforwood.com/product.

Proper use

DO NOT - Modify the structure of this product

DO NOT - Use for commercial purposes

DO NOT - Play on the table

DO NOT - Leave spilled liquids on the table

 $\ensuremath{\text{DO NOT}}$ - Use the table if it is damaged

DO NOT - Perform temporary repairs

DO NOT - Use outdoors

The return

Stress-free returns when we take care of it.

Feel free to call us at


1-888-909-5546

or send us a message at


help@allforwood.com.

We'll provide you with a hassle-free replacement at no cost.

Replacement



Return



We really want to save you the trouble of re-packaging and returning your item, because let's be honest, no one has time for that.

Warranty

This product includes a specific warranty period starting from the purchase date. To register your product, simply scan the QR code with your phone

Scan me!

For Warranty



Need Help?

Toll-free at 1-888-909-5546 Help (), allforwood.com www.allforwood.com